

RETAIL WEIGHING SOLUTION™

# PR-II series

## Price Computing Scale

As an electronic price-indicating scale with a maximum of 1/30,000 resolution, PR-II is designed in a low profile to be conveniently used in open market such as butcher's shop and groceries.



Pole Type

High Resolution for Weighing (Max. 1/30,000, Certificate 1/3,000 dual)

Low Profile Design

Up to 7 Direct PLUs Memory Function

LCD Display & Back light (White)

Low Profile Design

Existing Products

PR-II



7 Direct PLUs



LCD Display & White Back light



Scan with your smartphone to find more products



# PR-II series

## Price Computing Scale



### FEATURE

- High Resolution for Weighing (Max. 1/30,000)  
- A maximum of 900 hours of battery life when used with Mn and Pb batteries together
- Low Profile Design  
- Excellent applicability in open market with a low body
- Hi / OK / Low Limit Function
- USB Port for COMM. & Power (Option)



- Price Summation & Pay Function
- Up to 7 Direct PLUs Memory Function



- LCD Display & Back light (White)



- Rear Display for Customer (Bench type)

### OPTION

- RS-232 (Print, Command)
- Pole Type
- Mn Battery
- USB Port



### SPECIFICATIONS

MODEL	PR2-03	PR2-06	PR2-15	PR2-30
Capacity	3kg	6kg	15kg	30kg
e	0.5/0.2/0.1(g) 1/0.5g(certificated)	1/0.5/0.2(g) 1/0.5g(certificated)	2/1/0.5(g) 5/2/1g(certificated)	5/2/1(g) 10/5g(certificated)
Resolution	1/3,000 – 1/30,000	1/3,000 – 1/30,000	1/3,000 – 1/30,000	1/3,000 – 1/30,000
Display	6/6/6 Digit LCD & Back light (White) Minimum			
Symbols	STABLE, ZERO, TARE, Battery Remaining battery life indicated HI / OK / LO & Lb & 100g & Oz & ADD & PAY(Triangular symbol indicated)			
Keys	NUMBER, ZERO, TARE, FUNCTION, M1 – M7 KEY			
Functions	Direct PLU 7, Unit Conversion, Power Sleep Mode, Backlight Mode, Price Summation and Pay Function			
Operation Time	Approx. D size Battery = 500hr Or Pb Battery = 400hr (Backlight off) Approximately 900 hours consecutively when equipped with Mn Battery and Pb Battery together			
Option	RS-232 (Print, Command), Pole Type, Mn Battery, USB Port			
Power	1.5V x 3 units (D size Battery) or Pb battery 4V 4Ah or 6V Adapter			
Dimensions	330 (W) x 380(D) x 105(H)			
Platter Size	330 (W) x 235(D)			

### DIMENSION

